

Computer Vision

Bogdan Alexe

bogdan.alexe@fmi.unibuc.ro

University of Bucharest, 2nd semester, 2023-2024

LSEG Challenge



LSEG

Discover the world of Quant!

An event highlighting the congruence between the business and academic industry.

- Tuesday, 14 May
- 18:00
- The Institute of Data Science, Popa Tatu Street, Bucharest

An initiative organised by LSEG Romania in partnership with University of Bucharest, Faculty of Mathematics.

Register between 16 - 24 April
and showcase your Quant skills
to win the big prize of 300€.



SCAN ME

LSEG Challenge

**Discover the
world of Quant!**



Enter de competition between
16 - 24 April 2024




Discover the world of Quant
and the business opportunities for your career in LSEG Romania.

Administrative

Next week, 30th of April we don't do the lecture
(I'm away)

Project 1 – fake test added



Course structure

1. Features and filters: low-level vision

Linear filters, color, texture, edge detection, template matching

2. Grouping and fitting: mid-level vision

Fitting curves and lines, robust fitting, RANSAC, Hough transform, segmentation

3. Multiple views

Local invariant feature and description, epipolar geometry and stereo object instance recognition

4. Object Recognition: high – level vision


Object classification, object detection, part based models, bovw models

5. Video understanding

Object tracking, background subtraction, motion descriptors, optical flow

Goal: Recovery of 3D structure

- When certain assumptions hold, we can recover structure from a single view
- In general, we need *multi-view geometry*



- But first, we need to understand the geometry of a single camera...

Image formation






Image formation



Let's design a camera


- Idea 1: put a piece of film in front of an object
- Do we get a reasonable image?

Pinhole camera




- Idea 2: add a barrier to block off most of the rays
- This reduces blurring
 - The opening known as the **aperture**

Pinhole camera



- Captures **pencil of rays** – all rays through a single point: **aperture, center of projection, optical center, focal point, camera center**
- The image is formed on the **image plane**

Pinhole camera




f = focal length

C = center of the camera


Note: instead of dealing with an image that is upside down, most of the time we will pretend that the image plane is in front of the camera center.

Pinhole projection model



- To compute the projection P' of a scene point P , form the **visual ray** connecting P to the **camera center C** and find where it intersects the **image plane**


Pinhole projection model



- The coordinate system
 - The optical center (C) is at the origin
 - The image plane is parallel to xy -plane and perpendicular to the z -axis, which is the *optical axis* (gives the depth in 3D)

Pinhole projection model

Under the pinhole camera model, a point in space with coordinates $P = (X, Y, Z)^T$ is mapped to the point on the image plane where a line joining the point P to the centre C of projection meets the image plane.



- Projection equations – derived using similar triangles

$$\frac{f}{Z} = \frac{y}{Y}, \frac{f}{Z} = \frac{x}{X}$$

$$(X, Y, Z) \rightarrow \left(f \frac{X}{Z}, f \frac{Y}{Z}\right)$$


$$P(X, Y, Z) \rightarrow P'\left(f \frac{X}{Z}, f \frac{Y}{Z}, f\right)$$

3D world
coordinates


2D image
coordinates

Dimensionality reduction: from 3D to 2D

3D world



2D image



Point of observation

Projection can be tricky...




Projection can be tricky...



CoolOpticalIllusions.com

Making of 3D sidewalk art: <http://www.youtube.com/watch?v=3SNYtd0Ayt0>

Single-view ambiguity



A point in the 2D image corresponds to a ray in the 3D world. By projecting from 3D to 2D we loose depth.

Single-view ambiguity



Single-view ambiguity




[Rashad Alakbarov shadow sculptures](#)

Single-view ambiguity



Rashad Alakbarov shadow sculptures

Dimensionality reduction: from 3D to 2D



Point of observation

What properties of the world are preserved?

- Straight lines, incidence


What properties are not preserved?

- Angles, lengths

Projective Geometry


What is lost?

- Length



Length is not preserved


The camera projection scales the apparent height of objects by the inverse of the depth. This results in the well-known effect that objects farther away from the camera look smaller.



Projective Geometry

What is lost?


- Length
- Angles



Projective Geometry



What is preserved?

- Straight lines are still straight



Fronto-parallel planes


- What happens to the projection of a pattern on a plane parallel to the image plane?
 - All points on that plane are at a fixed *depth Z*
 - The pattern gets scaled by a factor of f/Z , but angles and ratios of lengths/areas are preserved




$$(X, Y, Z) \rightarrow (f \frac{X}{Z}, f \frac{Y}{Z}) = (X \frac{f}{Z}, Y \frac{f}{Z})$$

Vanishing points and lines

Parallel lines in the world intersect in the image at a “vanishing point”




Vanishing points and lines




- The projections of parallel 3D lines intersect at a **vanishing point**
- The projection of parallel 3D planes intersect at a **vanishing line**
- If a set of parallel 3D lines are also parallel to a particular plane, their vanishing point will lie on the vanishing line of the plane
- Not all lines that intersect are parallel
- Vanishing point \leftrightarrow 3D direction of a line
- Vanishing line \leftrightarrow 3D orientation of a surface

Vanishing points and lines



Constructing the vanishing point of a line





If we have another line in the scene parallel to the first one, it will have the same vanishing point

Vanishing lines of planes



How do we construct the vanishing line of a plane?

Vanishing lines of planes



- *Horizon*: vanishing line of the ground plane
 - All points at the same height as the camera project to the horizon
 - Points higher (resp. lower) than the camera project above (resp. below) the horizon
 - Provides way of comparing height of objects


Vanishing lines of planes




Is the parachutist above or below the camera?

A: The parachutist is below the horizon, so is below the camera

Comparing heights




Measuring height



Pinhole projection model

Under the pinhole camera model, a point in space with coordinates $P = (X, Y, Z)^T$ is mapped to the point on the image plane where a line joining the point P to the centre C of projection meets the image plane.



- Projection equations – derived using similar triangles

$$\frac{f}{Z} = \frac{y}{Y}, \frac{f}{Z} = \frac{x}{X}$$

$$(X, Y, Z) \rightarrow \left(f \frac{X}{Z}, f \frac{Y}{Z}\right)$$

$$P(X, Y, Z) \rightarrow P'\left(f \frac{X}{Z}, f \frac{Y}{Z}, f\right)$$

3D world
coordinates

2D image
coordinates

Homogeneous coordinates

- Is this a linear transformation? $(X,Y,Z) \rightarrow (f\frac{X}{Z}, f\frac{Y}{Z})$
 - no - division by z is nonlinear

Trick to make it linear: add one more coordinate, go from Cartesian to homogenous coordinates

$$(x,y) \Rightarrow \begin{bmatrix} x \\ y \\ 1 \end{bmatrix}$$

Cartesian image coordinates homogeneous image coordinates

$$(X,Y,Z) \Rightarrow \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

Cartesian Scene coordinates scene coordinates

$$\begin{bmatrix} f & 0 & 0 & 0 \\ 0 & f & 0 & 0 \\ 0 & 0 & 1 & 0 \end{bmatrix} \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix} = \begin{bmatrix} fX \\ fY \\ Z \\ 1 \end{bmatrix} \Rightarrow \begin{bmatrix} fX / Z \\ fY / Z \end{bmatrix}$$

Homogeneous Coordinates Cartesian Coordinates

Homogeneous coordinates

Conversion

Converting from *Cartesian* to *homogeneous* coordinates

$$(x, y) \Rightarrow \begin{bmatrix} x \\ y \\ 1 \end{bmatrix}$$

homogeneous image
coordinates

$$(X, Y, Z) \Rightarrow \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

homogeneous scene
coordinates

Converting from *homogeneous* to *Cartesian* coordinates

$$\begin{bmatrix} x \\ y \\ w \end{bmatrix} \Rightarrow (x / w, y / w)$$

Cartesian
coordinates

$$\begin{bmatrix} X \\ Y \\ Z \\ W \end{bmatrix} \Rightarrow (X / W, Y / W, Z / W)$$

Cartesian
coordinates

Homogeneous coordinates

Invariant to scaling

$$k \begin{bmatrix} x \\ y \\ w \end{bmatrix} = \begin{bmatrix} kx \\ ky \\ kw \end{bmatrix} \Rightarrow \begin{bmatrix} \frac{kx}{kw} \\ \frac{ky}{kw} \\ \frac{kw}{kw} \end{bmatrix} = \begin{bmatrix} \frac{x}{w} \\ \frac{y}{w} \\ 1 \end{bmatrix}$$

Homogeneous
Coordinates

Cartesian
Coordinates

Point in Cartesian is a ray in Homogeneous

Basic geometry in homogeneous coordinates

- Line equation: $ax + by + c = 0$

$$line_i = \begin{bmatrix} a_i \\ b_i \\ c_i \end{bmatrix}$$

- Append 1 to pixel coordinate to get homogeneous coordinate

$$p_i = \begin{bmatrix} x_i \\ y_i \\ 1 \end{bmatrix}$$


- Line given by cross product of two points

$$line_{ij} = p_i \times p_j$$

- Intersection of two lines given by cross product of the lines

$$q_{ij} = line_i \times line_j$$


Useful reference



Useful reference

Cookies

This website uses Google Analytics to help us improve the website content. This requires the use of standard Google Analytics cookies, as well as a cookie to record your response to this confirmation request. If this is OK with you, please click 'Accept cookies', otherwise you will see this notice on every page. For more information, please [click here](#).



Multiple View Geometry in Computer Vision Second Edition

Richard Hartley and Andrew Zisserman,
Cambridge University Press, March 2004.

Sample chapters

- Contents [pdf](#)
- Introduction [pdf](#)
- Epipolar Geometry and the Fundamental Matrix [pdf](#)
- The Trifocal Tensor [pdf](#)
- Bibliography [pdf](#)

Figures

- [Download figures](#) in pdf, png, bmp or postscript format.

Clarifications

- Image rectification (chapter 11) [pdf](#)
- Number of linearly independent trilinear relations (chapter 17) [pdf](#) [mathematica](#)

Also Available

See the [First Edition](#)'s page for sample chapters, downloadable figures, corrections and errata pertaining to the first edition.

Buy Online

Amazon: [Second edition](#).
CUP: [Second edition](#).

Basic geometry in homogeneous coordinates

- Line given by cross product of two points


$$p_i = \begin{bmatrix} x_i \\ y_i \\ 1 \end{bmatrix} \quad p_j = \begin{bmatrix} x_j \\ y_j \\ 1 \end{bmatrix} \quad \text{line}_{ij} = p_i \times p_j = \begin{vmatrix} e_1 & e_2 & e_3 \\ x_i & y_i & 1 \\ x_j & y_j & 1 \end{vmatrix}$$

$$e_1 = \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix}, e_2 = \begin{bmatrix} 0 \\ 1 \\ 0 \end{bmatrix}, e_3 = \begin{bmatrix} 0 \\ 0 \\ 1 \end{bmatrix}$$

Basic geometry in homogeneous coordinates

- Line given by cross product of two points

$$p_1 = \begin{bmatrix} 1 \\ 2 \\ 1 \end{bmatrix} \quad p_2 = \begin{bmatrix} 2 \\ 3 \\ 1 \end{bmatrix} \quad line_{12} = p_1 \times p_2 = \begin{vmatrix} e_1 & e_2 & e_3 \\ 1 & 2 & 1 \\ 2 & 3 & 1 \end{vmatrix}$$
$$line_{12} = 2e_1 + 3e_3 + 2e_2 - 4e_3 - 3e_1 - e_2 = -e_1 + e_2 - e_3 = \begin{bmatrix} -1 \\ 1 \\ -1 \end{bmatrix}$$



Basic geometry in homogeneous coordinates


- Line given by cross product of two points

$$p_1 = \begin{bmatrix} 1 \\ 2 \\ 1 \end{bmatrix}$$

$$p_2 = \begin{bmatrix} 2 \\ 3 \\ 1 \end{bmatrix}$$

$$\text{line}_{12} = p_1 \times p_2 = \begin{vmatrix} e_1 & e_2 & e_3 \\ 1 & 2 & 1 \\ 2 & 3 & 1 \end{vmatrix}$$

$$\text{line}_{12} = 2e_1 + 3e_3 + 2e_2 - 4e_3 - 3e_1 - e_2 = -e_1 + e_2 - e_3 = \begin{bmatrix} -1 \\ 1 \\ -1 \end{bmatrix}$$




$$\text{line}_{12} : ax + by + c = 0, a = -1, b = 1, c = -1$$

$$\text{line}_{12} : -x + y - 1 = 0$$

Basic geometry in homogeneous coordinates

- Line given by cross product of two points

$$p_1 = \begin{bmatrix} 1 \\ 2 \\ 1 \end{bmatrix} \quad p_2 = \begin{bmatrix} 2 \\ 3 \\ 1 \end{bmatrix} \quad p_3 = \begin{bmatrix} 1 \\ 1 \\ 1 \end{bmatrix} \quad p_4 = \begin{bmatrix} 2 \\ 2 \\ 1 \end{bmatrix} \quad line_{34} = p_3 \times p_4 = \begin{vmatrix} e_1 & e_2 & e_3 \\ 1 & 1 & 1 \\ 2 & 2 & 1 \end{vmatrix} = \begin{bmatrix} 1 \\ -1 \\ 0 \end{bmatrix}$$



$$line_{12} : -x + y - 1 = 0$$

$$line_{34} : x - y = 0$$

Basic geometry in homogeneous coordinates


- Intersection of two lines given by cross product of the lines

$$line_{12} : -x + y - 1 = 0$$

$$line_{34} : x - y = 0$$

$$line_{56} : x + y + 1 = 0$$

$$p = line_{12} \times line_{56} = \begin{vmatrix} e_1 & e_2 & e_3 \\ -1 & 1 & -1 \\ 1 & 1 & 1 \end{vmatrix} = \begin{bmatrix} 2 \\ 0 \\ -2 \end{bmatrix} = -2 \begin{bmatrix} -1 \\ 0 \\ 1 \end{bmatrix}$$



Another problem solved by homogeneous coordinates

Intersection of parallel lines

$$line_{12} : -x + y - 1 = 0$$

Cartesian: (Inf, Inf)

Homogeneous: (-1, -1, 0)


$$line_{34} : x - y = 0$$

Cartesian: (Inf, Inf)

Homogeneous: (-1, 1, 0)

$$line_{56} : x + y + 1 = 0$$


$$line_{78} : x + y = 0$$




$$p = line_{12} \times line_{34} = \begin{vmatrix} e_1 & e_2 & e_3 \\ -1 & 1 & -1 \\ 1 & -1 & 0 \end{vmatrix} = \begin{bmatrix} -1 \\ -1 \\ 0 \end{bmatrix}$$

$$p = line_{56} \times line_{78} = \begin{vmatrix} e_1 & e_2 & e_3 \\ 1 & 1 & 1 \\ 1 & 1 & 0 \end{vmatrix} = \begin{bmatrix} -1 \\ 1 \\ 0 \end{bmatrix}$$


How can we measure the size of 3D objects from an image?




Perspective cues




Perspective cues




Perspective cues




Comparing heights



Measuring height



Measuring height without a ruler




Compute Z from image measurements

The cross ratio

- A Projective Invariant
 - Something that does not change under projective transformations (including perspective projection)

The cross-ratio of 4 collinear points



$$\frac{\|\mathbf{P}_3 - \mathbf{P}_1\| \|\mathbf{P}_4 - \mathbf{P}_2\|}{\|\mathbf{P}_3 - \mathbf{P}_2\| \|\mathbf{P}_4 - \mathbf{P}_1\|}$$

$$\mathbf{P}_i = \begin{bmatrix} X_i \\ Y_i \\ Z_i \\ 1 \end{bmatrix}$$


Can permute the point ordering

$$\frac{\|\mathbf{P}_1 - \mathbf{P}_3\| \|\mathbf{P}_4 - \mathbf{P}_2\|}{\|\mathbf{P}_1 - \mathbf{P}_2\| \|\mathbf{P}_4 - \mathbf{P}_3\|}$$

- $4! = 24$ different orders (but only 6 distinct values)

This is the fundamental invariant of projective geometry

Measuring height



scene points represented as $\mathbf{P} = \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$

$$\begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

$$\frac{\|\mathbf{B} - \mathbf{T}\| \|\infty - \mathbf{R}\|}{\|\mathbf{B} - \mathbf{R}\| \|\infty - \mathbf{T}\|} = \frac{H}{R}$$

scene cross ratio


$$\frac{\|\mathbf{b} - \mathbf{t}\| \|\mathbf{v}_Z - \mathbf{r}\|}{\|\mathbf{b} - \mathbf{r}\| \|\mathbf{v}_Z - \mathbf{t}\|} = \frac{H}{R}$$

image cross ratio


$$\begin{bmatrix} x \\ y \\ 1 \end{bmatrix}$$

image points as $\mathbf{p} = \begin{bmatrix} x \\ y \\ 1 \end{bmatrix}$

Measuring height $\uparrow v_z$





Measuring height $\uparrow v_z$



What if the point on the ground plane b_0 is not known?

- Here the guy is standing on the box, height of box is known
- Use one side of the box to help find b_0 as shown above

Pinhole camera model



$$(X, Y, Z) \mapsto (fX/Z, fY/Z)$$

$$\begin{pmatrix} X \\ Y \\ Z \\ 1 \end{pmatrix} \mapsto \begin{pmatrix} fX \\ fY \\ Z \end{pmatrix} = \begin{bmatrix} f & & & \\ & f & & \\ & & 1 & 0 \end{bmatrix} \begin{pmatrix} X \\ Y \\ Z \\ 1 \end{pmatrix}$$



$$\mathbf{x} = \mathbf{P}\mathbf{X}$$

\mathbf{x} = homogenous coordinates in the image plane

\mathbf{X} = homogenous coordinates in the 3D scene


\mathbf{P} = 3x4 homogeneous camera projection matrix

Principal point



- **Principal point (p):** point where principal axis intersects the image plane
- Normalized coordinate system: origin of the image is at the principal point
- Image coordinate system: origin is in the corner

Principal point offset




We want the principal point to map to (p_x, p_y) instead of $(0,0)$

$$(X, Y, Z) \mapsto (fX/Z + p_x, fY/Z + p_y)$$

$$\begin{pmatrix} X \\ Y \\ Z \\ 1 \end{pmatrix} \mapsto \begin{pmatrix} fX/Z + p_x \\ fY/Z + p_y \\ Z \\ 1 \end{pmatrix} = \begin{bmatrix} f & p_x & 0 \\ f & p_y & 0 \\ 1 & 0 & 1 \end{bmatrix} \begin{pmatrix} X \\ Y \\ Z \\ 1 \end{pmatrix}$$

Principal point offset




principal point:

$$(p_x, p_y)$$

$$\begin{bmatrix} f & p_x & 0 \\ f & p_y & 0 \\ 1 & 0 \end{bmatrix} \begin{pmatrix} X \\ Y \\ Z \\ 1 \end{pmatrix}$$

Principal point offset



principal point:

$$(p_x, p_y)$$

$$\underbrace{\begin{bmatrix} f & p_x \\ f & p_y \\ 1 & \end{bmatrix}}_{\text{calibration matrix } K} \begin{bmatrix} 1 & 0 & X \\ 1 & 0 & Y \\ 1 & 0 & Z \\ 1 & \end{bmatrix} = \begin{bmatrix} f & p_x & 0 & X \\ f & p_y & 0 & Y \\ 1 & 0 & 1 & Z \\ 1 & \end{bmatrix} \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

projection matrix $[I | 0]$

$P = 3 \times 4$ homogeneous camera projection matrix

$P = K[I | 0]$

Camera coordinate frame

$$\mathbf{x} = \mathbf{P}\mathbf{X} = \mathbf{K}[I|0] \begin{pmatrix} X \\ Y \\ Z \\ 1 \end{pmatrix} = K[I | 0] X_{cam}$$

K - calibration matrix

$\mathbf{X}_{cam} = (X, Y, Z, 1)^T$ = camera is assumed to be located at the origin of a Euclidean coordinate system with the principal axis of the camera pointing straight down the Z-axis, and the point \mathbf{X}_{cam} is expressed in this coordinate system. Such a coordinate system may be called the ***camera coordinate frame***.


In general, points in space will be expressed in terms of a different Euclidean coordinate frame, known as the ***world coordinate frame***. The two coordinate frames are related via a rotation and a translation.

World coordinate frame

$$\mathbf{x} = \mathbf{P}\mathbf{X} = K[I \mid 0]\mathbf{X}_{cam}$$


$\mathbf{X}_{cam} = (X, Y, Z, 1)^T$ = expressed in the *camera coordinate frame*.

In general, points in space will be expressed in terms of a different Euclidean coordinate frame, known as the *world coordinate frame*. The two coordinate frames are related via a rotation \mathbf{R} and a translation \mathbf{t} .




Camera calibration: figuring out transformation from *world* coordinate system to *image* coordinate system

Camera rotation and translation



- In general, the *camera* coordinate frame will be related to the *world* coordinate frame by a rotation and a translation
- Conversion from world to camera coordinate system
(in non-homogeneous coordinates):

Camera rotation and translation



- The diagram shows two coordinate systems: a camera coordinate system and a world coordinate system.

 - Camera Coordinate System:** A vertical grey plane represents the camera's image plane. A point C is located in front of the plane. A green line segment connects C to a point \tilde{C} on the plane. The camera's optical axis is shown as a blue line passing through \tilde{C} . The horizontal axis is labeled x_{cam} and the vertical axis is labeled z_{cam} .
 - World Coordinate System:** A grey origin point o is at the bottom center. Three axes extend from o : a red vertical axis labeled z , a green horizontal axis labeled y , and a blue diagonal axis labeled x .
 - Transformation:** A blue arrow labeled R, t indicates the transformation from the world coordinate system to the camera coordinate system. It points from the world origin o towards the camera's optical axis.
 - Point X :** A point X is located in the world coordinate system. A green line segment connects X to its projection \tilde{C} on the camera's image plane.


$$\tilde{X}_{\text{cam}} = R(\tilde{X} - \tilde{C})$$

coords. of point in camera frame

coords. of a point in world frame

coords. of camera center in world frame

Camera rotation and translation




$$\tilde{\mathbf{X}}_{\text{cam}} = \mathbf{R}(\tilde{\mathbf{X}} - \tilde{\mathbf{C}}) \quad \begin{pmatrix} \tilde{\mathbf{X}}_{\text{cam}} \\ 1 \end{pmatrix} = \begin{bmatrix} \mathbf{R} & -\mathbf{R}\tilde{\mathbf{C}} \\ 0 & 1 \end{bmatrix} \begin{pmatrix} \tilde{\mathbf{X}} \\ 1 \end{pmatrix}$$

3D transformation
matrix (4×4)

Homogeneous coordinates

Camera rotation and translation




$$\tilde{\mathbf{X}}_{\text{cam}} = \mathbf{R}(\tilde{\mathbf{X}} - \tilde{\mathbf{C}})$$

$$\mathbf{X}_{\text{cam}} = \begin{bmatrix} \mathbf{R} & -\mathbf{R}\tilde{\mathbf{C}} \\ \mathbf{0} & 1 \end{bmatrix} \mathbf{X}$$

3D transformation
matrix (4×4)

Camera rotation and translation



$$x = P X = K [I \mid 0] X_{cam}$$

$$x = K [I \mid 0] \begin{bmatrix} R & -R\tilde{C} \\ 0 & 1 \end{bmatrix} X$$


2D transformation matrix (3×3)

calibration matrix K

perspective projection matrix (3×4)


3D transformation matrix (4×4)

Camera rotation and translation



$$x = K[R \mid -R\tilde{C}]X$$


Camera rotation and translation



$$x = K[R \mid t]X \quad t = -R\tilde{C}$$

3D Rotation of Points

Rotation around the coordinate axes, **counter-clockwise**:




$$R_x(\alpha) = \begin{bmatrix} 1 & 0 & 0 \\ 0 & \cos \alpha & -\sin \alpha \\ 0 & \sin \alpha & \cos \alpha \end{bmatrix}$$

$$R_y(\beta) = \begin{bmatrix} \cos \beta & 0 & \sin \beta \\ 0 & 1 & 0 \\ -\sin \beta & 0 & \cos \beta \end{bmatrix}$$

$$R_z(\gamma) = \begin{bmatrix} \cos \gamma & -\sin \gamma & 0 \\ \sin \gamma & \cos \gamma & 0 \\ 0 & 0 & 1 \end{bmatrix}$$

Pixel coordinates for CCD cameras



Pixel size:

$$\frac{1}{m_x} \times \frac{1}{m_y}$$

- m_x pixels per meter in horizontal direction,
 m_y pixels per meter in vertical direction

Skew parameter

$$K = \begin{bmatrix} \alpha_x & s & \beta_x \\ & \alpha_y & \beta_y \\ & & 1 \end{bmatrix}$$

- s skew- parameter
- usually $s = 0$
- $s \neq 0$ can be interpreted as a skewing of the pixel elements in the CCD array so that the x- and y-axes are not perpendicular. This is very unlikely to happen (might arise as a result of taking a image of an image)

7.4 Radial distortion

The assumption throughout these chapters has been that a linear model is an accurate model of the imaging process. Thus the world point, image point and optical centre are collinear, and world lines are imaged as lines and so on. For real (non-pinhole) lenses this assumption will not hold. The most important deviation is generally a radial distortion. In practice this error becomes more significant as the focal length (and price) of the lens decreases. See figure 7.4.

The cure for this distortion is to correct the image measurements to those that would have been obtained under a perfect linear camera action. The camera is then effectively again a linear device. This process is illustrated in figure 7.5. This correction must




Fig. 7.5. *The image of a square with significant radial distortion is corrected to one that would have been obtained under a perfect linear lens.*

be carried out in the right place in the projection process. Lens distortion takes place during the initial projection of the world onto the image plane, according to (6.2–p154). Subsequently, the calibration matrix (7.6) reflects a choice of affine coordinates in the image, translating physical locations in the image plane to pixel coordinates.


Camera parameters $\mathbf{P} = \mathbf{K}[\mathbf{R} \quad \mathbf{t}]$

- Intrinsic parameters
 - Principal point coordinates
 - Focal length
 - Pixel magnification factors
 - *Skew (non-rectangular pixels)*
 - *Radial distortion*

$$\mathbf{K} = \begin{bmatrix} m_x & & f & p_x \\ & m_y & & f \\ & & 1 & p_y \\ & & & 1 \end{bmatrix} = \begin{bmatrix} \alpha_x & & \beta_x \\ & \alpha_y & \beta_y \\ & & 1 \end{bmatrix}$$




radial distortion



correction

linear image



Camera parameters $\mathbf{P} = \mathbf{K}[\mathbf{R} \quad \mathbf{t}]$

- Intrinsic parameters

- Principal point coordinates
- Focal length
- Pixel magnification factors
- *Skew (non-rectangular pixels)*
- *Radial distortion*

- Extrinsic parameters

$$\mathbf{P} = \mathbf{K}[\mathbf{R} \quad -\mathbf{R}\tilde{\mathbf{C}}]$$

↑
coords. of
camera center
in world frame

- Rotation and translation relative to world coordinate system
- What is the projection of the camera center?

$$\mathbf{P}\mathbf{C} = \mathbf{K}[\mathbf{R} \quad -\mathbf{R}\tilde{\mathbf{C}}] \begin{bmatrix} \tilde{\mathbf{C}} \\ 1 \end{bmatrix} = 0$$

The camera center is the *null space* of the projection matrix!

Camera parameters $\mathbf{P} = \mathbf{K}[\mathbf{R} \quad \mathbf{t}]$

$$\mathbf{x} = \mathbf{K}[\mathbf{R} \quad \mathbf{t}] \mathbf{X}$$



$$\begin{bmatrix} \alpha_x & s & \beta_x \\ 0 & \alpha_y & \beta_y \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} r_{11} & r_{12} & r_{13} & t_x \\ r_{21} & r_{22} & r_{23} & t_y \\ r_{31} & r_{32} & r_{33} & t_z \end{bmatrix}$$

Degrees of freedom

$$\mathbf{x} = \mathbf{K}[\mathbf{R} \quad \mathbf{t}] \mathbf{X}$$



$$\begin{bmatrix} & & & 5 \\ \alpha_x & s & \beta_x & \\ 0 & \alpha_y & \beta_y & \\ 0 & 0 & 1 & \end{bmatrix} \begin{bmatrix} & & & 6 \text{ (3 for rotation and 3 for translation)} \\ r_{11} & r_{12} & r_{13} & t_x \\ r_{21} & r_{22} & r_{23} & t_y \\ r_{31} & r_{32} & r_{33} & t_z \end{bmatrix}$$

$$5 + 6 = 11 \text{ degrees of freedom} = 12 \text{ (matrix } 3 \times 4\text{)} - 1 \text{ (scale)}$$

How to calibrate the camera?



$$\mathbf{x} = \mathbf{K}[\mathbf{R} \quad \mathbf{t}] \mathbf{x}$$

$$\begin{bmatrix} wu \\ wv \\ w \end{bmatrix} = \begin{bmatrix} * & * & * & * \\ * & * & * & * \\ * & * & * & * \end{bmatrix} \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

Calibrating the Camera

Method 1: Use an object (calibration grid) with known geometry


- Given n points with known 3D coordinates X_i and known image projections x_i , estimate the camera parameters



Calibrating the Camera

Method 1: Use an object (calibration grid) with known geometry

- Given n points with known 3D coordinates X_i and known image projections x_i , estimate the camera parameters
- Get least squares solution (or non-linear solution)



$$\begin{bmatrix} wu \\ wv \\ w \end{bmatrix} = \begin{bmatrix} m_{11} & m_{12} & m_{13} & m_{14} \\ m_{21} & m_{22} & m_{23} & m_{24} \\ m_{31} & m_{32} & m_{33} & m_{34} \end{bmatrix} \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

Linear method

- Solve using linear least squares

$$\begin{bmatrix} wu \\ wv \\ w \end{bmatrix} = \begin{bmatrix} m_{11} & m_{12} & m_{13} & m_{14} \\ m_{21} & m_{22} & m_{23} & m_{24} \\ m_{31} & m_{32} & m_{33} & m_{34} \end{bmatrix} \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

- P has 11 degrees of freedom
- One 2D/3D correspondence gives us two linearly independent equations
 - 6 correspondences needed for a minimal solution

Linear method

- Solve using linear least squares

$$\begin{bmatrix} wu \\ wv \\ w \end{bmatrix} = \begin{bmatrix} m_{11} & m_{12} & m_{13} & m_{14} \\ m_{21} & m_{22} & m_{23} & m_{24} \\ m_{31} & m_{32} & m_{33} & m_{34} \end{bmatrix} \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

(X_i, Y_i, Z_i) – 3D world coordinates
(u_i, v_i) – 2D image coordinates

$$\begin{bmatrix} X_1 & Y_1 & Z_1 & 1 & 0 & 0 & 0 & -u_1X_1 & -u_1Y_1 & -u_1Z_1 & -u_1 \\ 0 & 0 & 0 & 0 & X_1 & Y_1 & Z_1 & 1 & -v_1X_1 & -v_1Y_1 & -v_1Z_1 & -v_1 \\ & & & & \vdots & & & & & & & \\ X_n & Y_n & Z_n & 1 & 0 & 0 & 0 & -u_nX_n & -u_nY_n & -u_nZ_n & -u_n \\ 0 & 0 & 0 & 0 & X_n & Y_n & Z_n & 1 & -v_nX_n & -v_nY_n & -v_nZ_n & -v_n \end{bmatrix} \begin{bmatrix} m_{11} \\ m_{12} \\ m_{13} \\ m_{14} \\ m_{21} \\ m_{22} \\ m_{23} \\ m_{24} \\ m_{31} \\ m_{32} \\ m_{33} \\ m_{34} \end{bmatrix} = \begin{bmatrix} 0 \\ 0 \\ \vdots \\ 0 \end{bmatrix}$$

Ap=0 form

Linear method

- Solve using linear least squares

$$\begin{bmatrix}
 X_1 & Y_1 & Z_1 & 1 & 0 & 0 & 0 & -u_1 X_1 & -u_1 Y_1 & -u_1 Z_1 & -u_1 \\
 0 & 0 & 0 & 0 & X_1 & Y_1 & Z_1 & 1 & -v_1 X_1 & -v_1 Y_1 & -v_1 Z_1 & -v_1 \\
 & & & & & & \vdots & & & & & \\
 X_n & Y_n & Z_n & 1 & 0 & 0 & 0 & -u_n X_n & -u_n Y_n & -u_n Z_n & -u_n \\
 0 & 0 & 0 & 0 & X_n & Y_n & Z_n & 1 & -v_n X_n & -v_n Y_n & -v_n Z_n & -v_n
 \end{bmatrix} = \begin{bmatrix}
 m_{11} \\
 m_{12} \\
 m_{13} \\
 m_{14} \\
 m_{21} \\
 m_{22} \\
 m_{23} \\
 m_{24} \\
 m_{31} \\
 m_{32} \\
 m_{33} \\
 m_{34}
 \end{bmatrix} = \begin{bmatrix}
 0 \\
 0 \\
 \vdots \\
 0 \\
 0
 \end{bmatrix}$$

$\mathbf{Ap=0}$ form

- Homogeneous least squares: find \mathbf{p} minimizing $\|\mathbf{Ap}\|^2$
 - Solution given by the eigenvector of $\mathbf{A}^T \mathbf{A}$ with smallest eigenvalue


Laboratory class 6

The goal of this lab is to introduce you to camera and scene geometry. Specifically we will estimate the camera projection matrix, which maps 3D world coordinates to image coordinates, as well as the fundamental matrix, which relates points in one scene to epipolar lines in another. The camera projection matrix and the fundamental matrix can each be estimated using point correspondences. To estimate the projection matrix (camera calibration), the input is corresponding 3D and 2D points. To estimate the fundamental matrix the input is corresponding 2D points across two images. We start by estimating the projection matrix and the fundamental matrix for a scene with ground truth correspondences. Then we'll move on to estimating the fundamental matrix using point correspondences from SIFT.

Tutorial on epipolar geometry is here: https://docs.opencv.org/master/da/de9/tutorial_py_epipolar_geometry.html or here: https://opencv-python-tutorials.readthedocs.io/en/latest/py_tutorials/py_calib3d/py_epipolar_geometry/py_epipolar_geometry.html

Data

We provide 2D and 3D ground truth point correspondences for the base image pair (pic_a.jpg and pic_b.jpg), as well as other images which will not have any ground truth dataset.



This laboratory consists of three parts: (1) estimating the projection matrix, (2) estimating the fundamental matrix, (3) estimating the fundamental matrix with unreliable SIFT matches using RANSAC.

Laboratory class 6



Laboratory class 6

